



Installation

Model specific instructions

For:

- [Triumph America EFI](#)
- [Triumph Speedmaster EFI](#)
- [Triumph Bonneville EFI](#)
- [Triumph Bonneville T100 EFI](#)
- [Triumph Scrambler EFI](#)
- [Triumph Thruxton 900 EFI](#)

These instructions are a model specific add-on to the general BoosterPlug installation instructions.

The general BoosterPlug installation instructions can be found in the "Downloads" section on the BoosterPlug.com website:

<http://www.boosterplug.com/shop/cms-downloads.html>

Installation Tips

- Install the BoosterPlug module as per the general installation papers.
- The pictures below should help you locate the AIT sensor where the BoosterPlug is installed.
- Remove the right hand side cover to get access to the AIT sensor.
- These are probably the easiest bikes to install the BoostePlug on :-)

Pictures

